

Setup Sheet
Series 804L - Autogen

Run Parameters			Configuration			Terminals	
Parameter	Default	Changes	Parameter	Default	Changes		
Unit	°F		P1	cALtC		Terminals 1A&1B	
AL1	1550		P2	nnnn		Out1	Alr1
AL1H	1		P3	0			
AL2	1950		P4	2502		Terminals 2A&2B	
AL2H	1		P11	AL11		Out2	Alr3
AL3	1800		P12	AL31			
AL3H	1		P13	NONE		Terminals 3A&3B	
oFS	0		P14	AL21		Out3	Not assigned
Flt	16		P21	Lo			
			P22	NONE		Terminals 4B&4A	
			P23	no		Out4	Alr2 (High Limit)
			P24	Hi			
			P25	NAN			
			P26	no			
			P27	Lo			
			P28	NONE			
			P29	no			
			P35	LAL			
			P37	AL2			
			P51	NONE			
			P52	NONE			
			P61	2			
			P62	19.2			
			P63	NONE			
			P64	NONE			
			P71	ACAL			
			P72	ACAL			
			P73	ACAL			
			P74	AL2			
P75	AL.1						
P76	2						
P77	4						
rEc.S	NONE						
rEc.L	NONE						
PHAS	NONE						

Super Systems Inc. Setup Sheet for Series 804L - Autogen
(Document #4656; : 3/11/2022; MCO #2320).
Visit us online at <http://www.supersystems.com>.