


Series 7EK to Series 808 Wiring Guide

Introduction

This manual will guide you through the process of wiring an 808 Series controller with a previously installed series 7EK controller. Note: the colors depicted in the images have no other meaning than to provide a quick visual reference for transferring wires from one controller to the next in a replacement scenario.

This manual is for the 808 only. If you are wiring an 808SR, refer to the guide for that device.



Super Systems Inc.

Page 1 of 2

7EK Wiring Conversion

Notes: {NO} = Normally Open Contact, {NC} = Normally Closed Contact

Procedure

When replacing the 7EK with an 808 controller its important to note that the terminal layout has changed. Below is the text description of the wiring conversion process.

1.Transfer Analog Input from 7EK to 808 as follows:

Terminal 1 to (V+)

Terminal 3 to (V-)

Terminal 4 to (VI)

2. Transfer from 7EK to 808 as follows:

Terminal 7 to (C)

Terminal 8 to (LA)

3. Transfer RS-485 communication from 7EK to 808 as follows:

Terminal 9 to (HD)

Terminal 10 to (HF)

Terminal 11 to (HE)

4. Transfer Analog Output from 7EK to 808 as follows:

Terminal 14 to (3A)

Terminal 15 to (3B)

5. Transfer Relay Outputs from 7EK to 808 as follows:

Terminal 19 to (1A)

Terminal 18 to (AA)

Terminal 22 to (2A)

6. Finally, Transfer Line and Relay Commons

L1 (Terminal 12) to (Terminal L)

L2 (Terminal 13) to (Terminal N)

Terminate the relay commons accordingly

Terminal 21 to (2B)

Terminal 20 to (1B)

(L) can be jumpered to (AB) on the 808 if used

Note: If used, Terminals 16 & 17 (Output 2) on the 7EK will only transfer to an 808SR Model.

| Rev. | Description | Date | MCO# |
|------|---|------------|------|
| - | Initial Release | 11/23/2016 | 2184 |
| A | Various changes to wiring and terminals | 4/11/2023 | 2334 |